

# Angle Modulation

- Angle modulation: frequency modulation (FM) or phase modulation (PM).
- Basic idea: vary frequency (FM) or phase (PM) according to the message signal.
- While AM is (almost) linear, FM or PM is highly nonlinear.
- FM/PM provide many advantages (main – noise immunity) over AM, at a cost of larger bandwidth.
- Demodulation may be complex, but modern ICs allow cost-effective implementation.
- Example: FM radio (high quality, not expensive receivers).

# Angle Modulation: Basic Definitions

- Angle-modulated signal (PM or FM) can be expressed as:

$$x(t) = A_c \cos(\psi(t))$$

- Phase modulation:

$$\psi(t) = \omega_c t + \phi(t), \quad \phi(t) = \Delta\phi \cdot m(t)$$

- Frequency modulation:

$$\psi(t) = \omega_c t + \int_0^t \Omega(\tau) d\tau, \quad \Omega(t) = \Delta\Omega \cdot m(t)$$

for a short period of time (small  $t$ ):  $\psi(t) \approx [\omega_c + \Omega(0)]t + \phi_0$

- Max phase deviation:  $\Delta\phi = \text{Max} \{|\phi(t)|\} = \text{Max} \{|\psi(t) - \omega_c t|\}$
- Max frequency deviation:  $\Delta\Omega = \text{Max} \{|\Omega(t)|\} = \text{Max} \{|\omega(t) - \omega_c|\}$
- Normalized message signal:  $|m(t)| \leq 1$

Note: deviation is w.r.t. unmodulated value.

# Angle Modulation: Parameters

- Instantaneous frequency:

$$\omega(t) = \frac{d\psi(t)}{dt} = \begin{cases} \omega_c + \frac{d\phi(t)}{dt} = \omega_c + \Delta\phi \frac{dm(t)}{dt}, & PM \\ \omega_c + \Omega(t) = \omega_c + \Delta\Omega \cdot m(t), & FM \end{cases}$$

- Instantaneous phase:


$$\psi(t) = \int_0^t \omega(\tau) d\tau = \begin{cases} \omega_c t + \phi(t) = \omega_c t + \Delta\phi \cdot m(t), & PM \\ \omega_c t + \int_0^t \Omega(\tau) d\tau = \omega_c t + \Delta\Omega \int_0^t m(\tau) d\tau, & FM \end{cases}$$

- Effect of mod. signal amplitude:  $M(t) = A \cdot m(t)$ ,  $\max[|m(t)|] = 1$

$$\begin{cases} \Delta\phi = k_p A, & PM \\ \Delta\Omega = k_f A, & FM \end{cases}$$

$k_f, k_p$  - modulation constants,  
 Hz/V & rad./V  
 ↑  
 measured in lab 3.

# Angle Modulation: Examples



# Example: Sinusoidal Modulating Signal

- Assume that  $m(t) = \cos(\omega_m t)$

- Instantaneous phase:

$$\psi(t) = \begin{cases} \omega_c t + \Delta\phi \cdot \cos(\omega_m t), & PM \\ \omega_c t + \frac{\Delta\Omega}{\omega_m} \sin(\omega_m t), & FM \end{cases}$$

- Modulated signal:

$$x(t) = \begin{cases} A_c \cos[\omega_c t + \Delta\phi \cdot \cos(\omega_m t)], & PM \\ A_c \cos\left[\omega_c t + \frac{\Delta\Omega}{\omega_m} \sin(\omega_m t)\right], & FM \end{cases}$$

- Modulation indices:

$$\begin{cases} \beta_p = \Delta\phi, & PM \\ \beta_f = \frac{\Delta\Omega}{\omega_m}, & FM \end{cases}$$



Valid in general case  
as well, with

$\omega_m \rightarrow$  max.  
modulating frequency

# Spectrum of Angle-Modulated Signal

- Consider sinusoidal modulating signal:

$$x(t) = A_c \cos[\omega_c t + \beta \cdot \sin(\omega_m t)] = \text{Re} \left[ A_c e^{j\beta \cdot \sin(\omega_m t)} e^{j\omega_c t} \right]$$

- Complex envelope is expanded in Fourier series:

$$C(t) = A_c e^{j\beta \cdot \sin(\omega_m t)} = A_c \sum_{n=-\infty}^{\infty} c_n e^{jn\omega_m t}$$


- Expansion coefficients are

$$c_n = \frac{1}{T_m} \int_0^{T_m} e^{j\beta \sin \omega_m t} e^{-jn\omega_m t} dt \stackrel{u=\omega_m t}{=} \frac{1}{2\pi} \int_0^{2\pi} e^{j(\beta \sin u - nu)} du = J_n(\beta)$$

- Finally, 
$$x(t) = A_c \sum_{n=-\infty}^{\infty} J_n(\beta) \cos[(\omega_c + n\omega_m)t]$$

$J_n(\beta)$  - Bessel function of 1st kind & n-th order,  $J_{-n}(\beta) = (-1)^n J_n(\beta)$

# Spectrum of Angle Modulation: $J_n(\beta)$







# Spectrum of Angle Modulation: $J_n(\beta)$

n	$\beta = 0.1$	$\beta = 0.2$	$\beta = 0.5$	$\beta = 1$	$\beta = 2$	$\beta = 5$	$\beta = 8$	$\beta = 10$	n
0	<u>0.998</u>	<u>0.990</u>	0.938	0.765	0.224	-0.178	0.172	-0.246	0
1	0.050	0.100	<u>0.242</u>	0.440	0.577	-0.328	0.235	0.043	1
2	0.001	0.005	0.031	<u>0.115</u>	0.353	0.047	-0.113	0.255	2
3				0.020	<u>0.129</u>	0.365	-0.291	0.058	3
4				0.002	0.034	0.391	-0.105	-0.220	4
5					0.007	0.261	0.186	-0.234	5
6					0.001	<u>0.131</u>	0.338	-0.014	6
7	the last significant spectral component:					0.053	0.321	0.217	7
8						0.018	0.223	0.318	8
9	$n = [\beta + 1]$					0.006	<u>0.126</u>	0.292	9
10						0.001	0.061	0.207	10
11						0.026	<u>0.123</u>	11	
12						0.010	0.063	12	
13						0.003	0.029	13	
14						0.001	0.012	14	
15	$x(t) = A_c \sum_{n=-\infty}^{\infty} J_n(\beta) \cos[(\omega_c + n\omega_m)t]$							0.004	15
16									



# Spectrum: Examples



# Bandwidth of Angle-Modulated Signal

- Power bandwidth (98% of the power) of angle-modulated signal (Carson's rule):

$$\Delta\omega \approx 2(\beta + 1)\omega_m$$

- Power bandwidth of PM and FM signals:

$$\Delta\omega \approx 2(\beta + 1)\omega_m = \begin{cases} 2(\Delta\phi + 1)\omega_m, & PM \\ 2(\Delta\Omega + \omega_m), & FM \end{cases}$$


- These expressions hold for a general modulating signal as well,  $\omega_m$  - the max. modulating frequency.
- Angle modulation with large index expands spectrum!

# Narrowband Angle Modulation

- Modulation index is low,  $\beta \ll 1$
- Modulated signal can be expressed as:

$$\begin{aligned} x(t) &= A_c \cos[\omega_c t + \beta \cdot \sin(\omega_m t)] = \\ &= A_c \cos \omega_c t + \frac{A_c \beta}{2} \cos(\omega_c + \omega_m)t - \frac{A_c \beta}{2} \cos(\omega_c - \omega_m)t \end{aligned}$$

- Similar to AM signal, the bandwidth is (both, PM & FM)



# Wideband Angle Modulation

- Modulation index is high,  $\beta \gg 1$


- The signal bandwidth is:

$$\Delta\omega \approx 2\beta\omega_m = \begin{cases} 2\Delta\phi \cdot \omega_m, & PM \\ 2\Delta\Omega, & FM \end{cases}$$

- Different for PM and FM!
- Wideband FM: the bandwidth is twice the frequency deviation. Does not depend on the modulating frequency.
- Wideband PM: the bandwidth depends on modulating frequency.
- Modulation index  $\beta =$  bandwidth expansion factor.

# PM Modulator

General principle:




Practical implementation:

$$\Delta\phi \approx k\Delta f, \quad \Delta f = f_c - f_0$$

$k =$  modulation constant  
 $f_0 =$  resonant frequency


Q.: sketch  $\Delta\phi(\Delta f)$



L.W. Couch II, Digital and Analog Communication Systems, Prentice Hall, 2001.

# FM Modulator


General principle:



Practical implementation:

Difficulty: frequency stability.


Suitable for narrowband FM only.



L.W. Couch II, Digital and Analog Communication Systems, Prentice Hall, 2001.


# Narrowband Angle Modulator

Small modulation index:  $\beta \ll 1$  




J.Proakis, M.Salehi, Communications Systems Engineering, Prentice Hall, 2002

# Indirect Wideband Angle Modulator




Frequency multiplier:



$$\boxed{\cos^2 \psi(t) = \frac{1}{2} [1 + \cos(2\psi(t))]} \xrightarrow{\text{BPF}} \boxed{\frac{1}{2} \cos(2\psi(t))}$$




# Indirect Wideband FM Transmitter (Amstrong)



**Figure 5.10** Armstrong indirect FM transmitter.

B.P. Lathi, Modern Digital and Analog Communications Systems, Oxford University Press

# Direct Wideband Angle Modulator




L.W. Couch II, Digital and Analog Communication Systems, Prentice Hall, 2001.

## Explain how it operates

- Hint: consider it without feedback first
- Explain why feedback is required
- Explain why frequency divider is required

# FM Demodulators



- FM-to-AM conversion:




- Possible candidate:  $|H(f)| = 2\pi f$  (differentiator)

# FM Slope Detector


- Circuit diagram:



- Magnitude frequency response: 




# Balanced Discriminator: Block Diagram




L.W. Couch II, Digital and Analog Communication Systems, Prentice Hall, 2001.

# Balanced Discriminator: Circuit Diagram



L.W. Couch II, Digital and Analog Communication Systems, Prentice Hall, 2001.

# Phased Locked Loop (PLL) Detector



$$v_{in}(t) = A_{in} \sin[\omega_c t + \varphi_{in}(t)]$$

$$v_1(t) = \frac{A_1 A_2}{2} \sin[\varphi_{in}(t) - \varphi_0(t)] + (2\omega_c) \text{term}$$

$$v_0(t) = A_0 \cos[\omega_c t + \varphi_0(t)]$$


$$\omega_{VCO}(t) = \frac{d}{dt}(\omega_c t + \varphi_0(t)) = \omega_c + \alpha v_2(t)$$

Informally,


$$\varphi_{in}(t) \approx \varphi_0(t)$$

$$v_2(t) \approx \frac{1}{\alpha} \frac{d}{dt} \varphi_{in}(t)$$

# PLL Detector: Linear Model




$$v_1(t) = \frac{A_1 A_2}{2} \sin[\phi_{in}(t) - \phi_0(t)] + (2\omega_c) \text{term}$$



$$v_2(t) = \frac{A_1 A_2}{2} \sin[\phi_{in}(t) - \phi_0(t)] \approx \frac{A_1 A_2}{2} (\phi_{in}(t) - \phi_0(t)) = K_d \Delta\phi(t)$$


$$\frac{d}{dt} \phi_0(t) = \alpha v_2(t)$$



$$v_2(t) = \frac{1}{\alpha} \frac{d}{dt} [\phi_{in}(t) - \Delta\phi(t)] \approx \frac{1}{\alpha} \frac{d}{dt} \phi_{in}(t)$$



# FM Demodulator: Lab 3



- explain its operation !

# Comparison of AM and FM/PM

- AM is simple (envelope detector) but no noise/interference immunity (low quality).
- AM bandwidth is twice or the same as the modulating signal (no bandwidth expansion).
- Power efficiency is low for conventional AM.
- DSB-SC & SSB – good power efficiency, but complex circuitry.
- FM/PM – spectrum expansion & noise immunity. Good quality.
- More complex circuitry. However, ICs allow for cost-effective implementation.

# Important Properties of Angle-Modulated Signals: Summary

- FM/PM signal is a nonlinear function of the message.
- The signal's bandwidth increases with the modulation index.
- The carrier spectral level varies with the modulation index, being 0 in some cases.
- Narrowband FM/PM: the signal's bandwidth is twice that of the message (the same as for AM).
- The amplitude of the FM/PM signal is constant (hence, the power does not depend on the message).

# Summary

- Angle modulation: PM & FM
- Spectra of angle-modulated signals. Modulation index.
- Narrowband (low-index) & wideband (large-index) modulation. Signal bandwidth.
- Relation between PM and FM.
- Generation of angle-modulated signals. Narrowband & wideband modulators.
- Demodulation of PM and FM signals. Slope detector & balanced discriminator. PLL detector.
- Comparison of AM and FM/PM.
- **Homework**: Reading: Couch, 5.6, 4.13, 4.14. Study carefully all the examples and make sure you understand them.